

Fire Inspector I & II

CHAPTER THIRTEEN SAFE HOUSEKEEPING PRACTICES



Slide 1	Welcome to Chapter 13 Safe Housekeeping Practices.
Slide 2	In this Chapter we will discuss:
	An overview of housekeeping
	 That good housekeeping is an effective fire prevention strategy
	 Housekeeping issues on the exterior of the building
	Blocked or obstructed access
	Obstructions to fire protection equipment
	 Protection of flammable liquid and gas equipment
	Fire exposure threats
	Wildland interface.
Slide 3	Then we will move on to interior housekeeping and discuss:
	 Spontaneous ignition and Oil waste, towels, and rags
	Dust and lint accumulations
	Mechanical equipment
	Combustible material storage
	High piled combustible storage
	Trash and recycling issues
	 Packing and shipping materials
	Flammable and combustible liquids
	 Painting, coating, finishing and lubricants
	Obstructions to fire protection equipment
	 Kitchen cooking hoods, exhaust ducts, and equipment
	Compressed gas cylinders
	 Correction of housekeeping issues
	And we will conclude this Chapter with the need for Fire Safety Plans and
	control of smoking.
Slide 4	One of the most effective tools a fire inspector has is a straightforward
	approach to good housekeeping. You will discover that it is not necessary to have years of experience to recognize and correct poor housekeeping issues.
	By simply using common-sense and following safe housekeeping practices, you
	can educate the building owner or occupant to the benefits of safe
	housekeeping. These benefits include reduced fire risk, safer working
	conditions, and increased productivity which can all be motivating factors for
	the building owner.
	the banding owner.
	Over the course of your career, by educating building owners and occupants, you will see a reduction of housekeeping problems, reduced fire risk, and safer buildings not only for the occupants, but also to any responding fire suppression crews.

Slide 5

When you encounter occupancies that have poor housekeeping practices, be mindful of other fire and life safety deficiencies. Poor housekeeping practices can be a telltale sign that other fire safety deficiencies are likely. Effective housekeeping can help control or eliminate potential hazards. If the sight of garbage, debris, clutter, and spills is accepted as normal, then other

Housekeeping is not just cleanliness. It includes keeping areas neat and orderly, maintaining exit routes and floors free from obstructions and trip hazards, and regularly removing waste materials so they do not accumulate.

more serious hazards may be taken for granted.

Slide 6

As a fire inspector, you will want to keep the four major fire and life safety objectives in mind when conducting inspections.

Objective 1 is to identify and eliminate any unnecessary fuels, to reduce fire growth potential and assist in extinguishment. In this case, all of the cardboard boxes are empty and just adding unnecessary fuel load. In addition, the tires are piled too close to the ceiling. Because this storage area is not sprinklered, the fire code requires a clearance of not less than 1 m between the top of the storage pile and the underside of the floor or roof deck to allow access for hose lines.

Objective 2 is to identify and communicate to the building owner any obstructions or impediments to egress, such as storage of materials. In this case, the swing of the marked exit door is impeded by a cooler and will not open. If this is a required exit door, it should swing out in the direction of exit travel not into the kitchen. Reversing the swing of the door is one long term solution but the immediate reduction of hazard is to move the cooler. If the door is not a required exit, then the exit sign should be removed. In either case, the door should be free to swing.

References:

NFC 3.2.2.3

Slide 7

Objective 3 is to control and/or eliminate sources of ignition. This can be accomplished by:

- Removing unnecessary sources of heat or replacing them with safer alternatives.
- Ensuring that the use of heat-producing equipment follows the manufacturers operation and maintenance instructions
- Install machinery and equipment which has been designed to minimize the risk of fire and explosions.
- Replace naked flame and radiant heaters with a central heating system.

Keep ducts and flues clean Ensure that all electrical fuses and circuit breakers are of the correct rating and suitable for the purpose. Ensure that sources of heat do not arise from faulty or overloaded electrical or mechanical equipment such as overheating bearings. • Where appropriate, require hot works permits for processes like welding or flame cutting. Institute smoking policies. Slide 8 **Objective 4** is to improve the safety for firefighters. If you look after the safety issues for the building occupants by minimizing the spread of fire, by reducing the fuel load, providing unobstructed access to exits, and minimizing ignition sources you are providing safer conditions for the firefighters as well. In these photos firefighters are fighting a fire in a sawdust collection system at a wood processing plant. The dust created a minor explosion that engulfed the firefighter with the hose line. Fortunately, he was not injured. By improving the safety for firefighters, the other objectives of safe housekeeping are looked after By having these four major fire and life safety objectives in mind during your fire inspection, you will have more success with getting the building owner to practice good housekeeping. Slide 9 The three basic requirements of good housekeeping can be identified as equipment arrangement and layout, material management, and operational neatness, cleanliness, and orderliness. As you conduct your fire inspection, take note on how material is arranged and handled. Is the material placed in the proper containers for disposal and are these containers suitable for the material? For example, are oily rags stored in a metal container with a metal lid? You should ask the building owner how often the material is removed from the container and where the material is disposed of. Operational neatness, cleanliness, and orderliness promotes fire safety. You should find out how often waste and trash is collected and disposed of. This will be dependent on what the process is, what kind, and how much waste is produced. Most occupancies that practice safe housekeeping have a maintenance schedule to ensure a clean and safe environment. Slide 10 As you conduct your fire inspection, pay special attention outside of the building as fires often start on the outside and spread to the building. This was covered in detail in Chapter 5 "Performing an Inspection" so we will only provide a brief review here.

Many building owners fail to recognize or understand the importance of applying safe housekeeping practices on the exterior of the building which include:

• Unobstructed fire department access which can delay or hinder access to the building and/or building services.

Clearly posting the building address so it is visible on approach. If there
are multiple buildings in a complex each building must be readily
identifiable.

Most local governments have addressing bylaws stipulating address requirements. Be mindful of outbuildings like storage sheds and shipping containers. These may contain flammables that could spread a fire to the building you are trying to protect.

Slide 11

Consider any obstructions that will hinder the ability for fire fighters to access fire protection equipment which could include fences, gates, or vegetation. Signs indicating the location of the fire protection equipment should be posted. These signs not only aid firefighters in locating the equipment, but they also provide a reminder to others to not block access.

Make sure that there are no fences or gates that interfere with exiting the building or accessing services.

In winter, snow and ice must be managed so access and egress to the building and fire protection equipment is maintained. Ensure utilities connections are readily accessible, not overgrown by vegetation and have tamper seals installed. When you encounter utility connections that are vulnerable to collision damage, ask the building owner to install barriers that will prevent damage.

Slide 12

As you conduct your fire inspection identify any waste material or business by-products that accumulate near the building. A fire that occurs on the exterior of a building can be easily spread into the building if the combustible material is stored to close. You should ensure during your fire inspection that combustible materials, like wooden pallets and/or tires, have a reasonable separation away from the building. If the material is no longer required ask the owner to get rid of it.

Section 2.4 of the fire code is entitled Fire Hazards and it says in part "Combustible waste materials in and around buildings shall not be permitted to accumulate in quantities or locations that will constitute an undue fire hazard." The material in this photo is domestic waste and should be removed right away as it presents a fire hazard and potential target for vandalism.

Slide 13

Some of the most common exterior fires are dumpsters, garbage, and recycling bins. They are often a target for vandals as they present an opportunity.

5

June 2021

Another cause of these types of fires is discarded ash from solid fuel appliances or smokers' materials.

The fire code says that "outdoor storage receptacles, such as dumpsters, used for combustible materials shall be located so that they do not create an undue fire hazard to surrounding buildings. Measures such as those described in NFPA 80A, "Protection of Buildings from Exterior Fire Exposures," must be taken to ensure that buildings are protected from fires in outdoor receptacles containing combustible materials.

During your fire inspection you can help prevent or minimize the damage to buildings by ensuring they are kept at least ten feet away from the building, that they are not stored under building roof eaves or overhangs or near windows where the fire can penetrate the glass and spread to the building interior. They should be kept in a secured area that is not accessible to the public. In this photo garbage and recycling containers are under the roof overhang but also located in an area that provides visual protection for a would-be fire setter.

You should recommend that the building owner provide a secure area away from the building, thus allowing for good housekeeping and preventing the spread of fire to the building.

References:

NFC 2.4.1.1 and A-2.4.1.1.(6)

Slide 14

Protection should be provided for flammable liquid and gas equipment and utilities. This should include protection from wildfire, tampering, and vehicle collision. In the case of potential collision damage, posts or bollards may be used to secure the area.

To protect the building and oil tank from an exposure fire, the vegetation around the oil tank in this photo should be removed.

In this photo, the oil tank is sitting directly on the ground and leaning against the building. It should be secured on a non-combustible stand. When full, a fuel tank of this size can weigh around 2,000 pounds. To stop unwanted movement, it should be properly anchored to a solid footing. Ideally, the foundation for a tank is a large concrete pad with a metal tank stand firmly bolted down. Wooden tank stands are no longer accepted.

Check the tank for rusting, corrosion, dents, or other signs of physical damage on the outside of the tank. This could be an indication of weak spots that are more susceptible to rupture and leakage.

More information and a guide to Oil Tanks is provided in the additional recourses section.

Slide 15

A growing concern for fire prevention officials is the increasing use of land near the wildland/urban interface. As towns and cities grow, the need for land development near the wildland urban interface becomes more common. As a fire inspector, one of your roles may be to educate property owners about the importance of fire-safe landscaping and the use of fire resistive building materials.

FireSmart Canada and many Provincial FireSmart organizations have programs, updates, and resources to help you establish or maintain a wildland urban interface community education program. These programs extend to the outdoor storage of materials which can provide ladder fuels. Fuels that can carry a fire burning in low-growing vegetation to taller vegetation is called ladder fuel. Examples of ladder fuels include combustible materials stored outdoors, grasses, low-lying tree branches, and shrubs under the canopy of larger trees. In areas prone to wildfire, creating a separation in vegetation by removing ladder fuels is an important task.

Slide 16

Through good housekeeping practices, building owners can prevent the buildup of ladder fuels between the building and/or storage area and the urban interface. As you inspect the exterior of the building and surrounding area, look for potential fuels like the wood pile in this photo. Embers from a wildland fire could easily land on this pile of dry firewood which would likely result in a total loss of this commercial building.

Also look for space between the urban interface and the area that requires protecting. This is referred to as a defensible space. The distance of the defensible space will depend on the slope, aspect, environmental factors, and type of combustibles present. Slope refers to the upward or downward topography of the land, fire normally burns faster up a slope. Aspect refers to the compass direction facing the fire and environmental refers to factors like wind and weather.

The recommended defensible space will vary depending on the location and vegetation type, so the fire inspector should work closely with the local forestry management agency professionals who are better trained to deal with these issues.

Slide 17	In this case a house survived a wildland fire while many around it did not. The house had a sprinkler placed on the roof that saved the structure. Because of the overhang of the eves the water did not reach the vinyl siding which melted due to radiant heat. It is lucky that the wood piled against the side of the home did not ignite as it would have resulted in a total loss fire.
Slide 18	As you move from the exterior of the building into the interior you should be thinking of three main life safety concerns – early fire detection, adequate exiting, and confining the fire. This in part, involves identifying any potential sources of ignition and fuel loads that could contribute to the rapid growth and spread of a fire. The cleanliness and general standard of housekeeping is indicative of the level of fire safety in the building.
	A business that keeps its operations neat and tidy will enjoy a reduced risk of fire. However, you should also recognize the overall cleanliness of the building is often based on the process and operations conducted. For example, dust can be expected to accumulate in a sawmill operation, but if it is managed appropriately, it does not present an undue hazard. If, however, it is not dealt with regularly, devasting results can occur. The ignitability of any dust-air mixture is based on the size of the particles, moisture content, and energy required for ignition.
Slide 19	There are numerous industries that produce dust including, food production, metal processing, wood products, chemical manufacturing, rubber and plastics, and coal fired plants.
	When inspecting operations that produce dust, you should identify the process and provide strategies to limit the potential hazard. The potential hazard comes in the form of combustible dust. Combustible dust is a finely divided solid material that presents a fire or explosion hazard when dispersed and ignited in air.
	It is very important to communicate to the building owner that they are responsible to minimize the accumulation of combustible dust on equipment and building surfaces. They should do this using suction rather than blowing with compressed air. Compressed air will make the dust airborne and easy to ignite and or explode. When you inspect buildings that house special processes, ensure dust collecting equipment is properly working and all safeguards are in place.
Slide 20	Fire inspectors should be familiar with Section 5.3 of the Fire Code which is entitled "Dust-Producing Processes" This section applies "to buildings or parts of buildings where combustible dusts are produced in quantities or concentrations that create an explosion or fire hazard."

It deals with:

- Dust Removal
- Cleaning Equipment
- Dust-Collecting Systems
- Dust Collectors
- Electrical Bonding and Grounding
- Explosion Venting
- Explosion Prevention Systems
- Ignition Sources.

It also provides specific references to Grain Handling and Storage Facilities and Woodworking Operations. For example, a portable extinguisher must be provided within 7.5 m of any machine producing wood dust, particles, or shavings.

Slide 21

Video.

Slide 22

When conducting your inspection consider the potential of spontaneous combustion. Spontaneous combustion is the occurrence of fire without the application of an external heat source. Due to chemical, biological, or physical processes, combustible materials can self-heat to a temperature high enough for ignition to occur. According to the NFPA, an estimated 14,070 fires occur annually in the US from spontaneous combustion.

The potential for spontaneous combustion can be reduced through good housekeeping. Products that are susceptible to spontaneous combustion should be stored in non-combustible containers with tight fitting lids and removed from the building daily. The building owner or occupant should have a policy to deal with oily waste, towels or rags.

Slide 23

Generally, businesses such as restaurants, woodworking shops, and automotive shops tend to deal with oily waste items, but laundries and dry cleaners can also experience spontaneous combustion. When cotton cloth, vegetable oil, and bleach have been combined, washed, and dried in laundry equipment, the cotton may spontaneously ignite. This photo shows rags that were washed and dried and then ignited. Luckily, the ignition happened during the day when workers were around and noticed the fire in the incipient stage and were able to extinguish it before it spread to other combustibles.

The NFPA "Fires Caused by Spontaneous Combustion or Chemical Reaction Fact Sheet", found in the addition resources section of this Chapter, says that one-quarter the spontaneous ignited fires in mercantile or business properties occurred in laundry or dry-cleaning facilities and one-quarter of the spontaneous fires in manufacturing properties began with oily rags.

Slide 24

When doing an inspection in buildings with laundry facilities make sure to check for lint both inside and outside the building. As you walk around the exterior check dryer vents for signs of lint accumulation like that shown in this photo. Lint is visible at the outlet and on the ground below, so the vent requires immediate cleaning or use of the dryer should be discontinued.

Dryer vents should be cleaned any time there is an indication of a buildup of lint, but they should be cleaned at least annually. Lint traps are required by the fire code to be cleaned after each use. If lint is a problem, additional inline lint traps, like the one shown in these photos, can be installed that are easily accessible for cleaning.

Slide 25

Vent outlet caps or screens should also be in place to avoid unwanted entry by water, snow, ice, or small animals that may building nests that could eventually block the air flow as shown in this photo. Make sure the outdoor vent covering opens freely when the dryer is on. If the vent covers are broken or not operating properly, they should be replaced.

Inspect the venting system behind the dryer to ensure it is not damaged or restricted and that the area is clean. Often this is an area where lint and dirt will accumulate.

Reference:

BC 9.32.1.(2) and A-9.32.1.3.(2) Venting of Laundry-Drying Equipment

Slide 26

Make sure that the dryer vent is securely connected to the dryer. In this case the vent is not connected so the dryer is venting directly into the laundry room.

The building code requires laundry-drying vents to be constructed of a smooth corrosion-resistant material, however this applies to the piping and ducting located within the wall assembly and not to the often-flexible duct used to connect the appliance to the rigid exhaust vent duct.

Accordion type plastic flexible dryer vents should be strongly discouraged as they get brittle from heat over time and lint tends to build up inside as can be seen in this photo.

Accordion type aluminium ducts are much better than plastic but whenever possible smooth, sheet metal exhaust ducts that terminate on the outside of the building should be used.

Reference:

	NPC 0.22.1 (2) and A. 0.22.1.2 (2) Venting of Laundry Drying Equipment
Slide 27	NBC 9.32.1.(2) and A-9.32.1.3.(2) Venting of Laundry-Drying Equipment One of the most common issues in every building is the lack of storage space,
Silde 27	which often leads to unsafe storage of materials. As you conduct your fire
	inspection, ensure you inspect areas hidden from plain sight as these are often
	used for storage. For example, building occupants may use vacant rooms,
	service rooms, and even the space underneath stairs that are not designed for
	storage.
	In this photo the space under the stairs has been used. This may be permissible, but the space would have to be properly fire separated, normally
	by applying gypsum board. If the building has a fire alarm system, detection
	will have to be installed, and if the building is sprinkler protected, a sprinkler
	head would have to provide adequate coverage.
Slide 28	If stored materials are blocking an exit, or impeding access to an exit, the
	building owner or occupant should immediately clear the path to the exit. In
	this case furniture on display is blocking the exit door, the exit light is burned
	out and there is no portable fire extinguisher where one is indicated by the
	sign. These deficiencies should be corrected right away.
	In this case storage is blocking access to the exit door, and the storage is piled
	in such a way that it is unstable and could fall over and further block the exit.
	As you conduct your fire inspection, identify if stored materials are too close to
	potential ignition sources like, hot water heaters, boilers, space heaters, and
	even light bulbs.
	If storage impedes access to building services, it should be moved. In this case
	access to the main electrical panels and sub-panels is obstructed.
	As these deficiencies are easily corrected, they should be done immediately or
	as soon as reasonably possible.
	The fire code says that combustible materials, other than those for which the
	location, room, or space is designed, are not permitted to accumulate in any
	part of an elevator shaft, ventilation shaft, means of egress, service room, or
	service space. The fire code goes on to say that:
	"Horizontal concealed spaces, such as crawl spaces and ceiling spaces, shall
	not be used for the storage of combustible materials and combustible
	materials shall not be stored on a roof or adjacent to any building which would
	create a fire hazard to the building or its occupants."
	References:
	neierences.

	NEC 2.C2
01:1 00	NFC - 2.6.3
Slide 29	 The fire code says that combustible materials, other than those for which the location, room, or space is designed, are not permitted to accumulate in any part of an elevator shaft, ventilation shaft, means of egress, service room, or service space. The fire code goes on to say that: Horizontal concealed spaces, such as crawl spaces and ceiling spaces, shall not be used for the storage of combustible materials. In this case, the space between the roof trusses is used for storage which should be removed. The code also says that "combustible materials shall not be stored on a roof or adjacent to any building which would create a fire hazard to the building or its
	occupants". This photo shows wooden pallets piled against the outside of the building. Should this catch fire, significant damage to the building can be expected so the combustibles should be removed. References: NFC - 2.4.1 NFC - 2.6.3
Slide 30	Service rooms are defined by the fire code as — "a room provided in a building to contain equipment associated with building services". Typical examples of service rooms include boiler rooms, furnace rooms, incinerator rooms, garbage handling rooms and rooms to accommodate air-conditioning or heating appliances, pumps, compressors, and electrical equipment. Rooms such as elevator machine rooms and common laundry rooms are not considered to be service rooms.
	The fire code specifically says that "Electrical equipment vaults shall not be used for storage purposes" Electrical vaults are not defined in the fire code. Some fire inspectors use this clause to say that storage is not permitted in an electrical room which is also not a defined term. Electrical rooms are covered by the typical examples of service rooms provided in the notes section of part 2 of the fire code. Some inspectors allow storage in electrical rooms if sufficient access is provided to the electrical panels while others prohibit storage in electrical rooms all together.
	Either is correct depending on the hazard and local policy. Many jurisdictions allow storage in electrical rooms if the material stored is non-combustible, securely piled, and does not impede access to the electrical equipment.
	References: NFC - 2.4.1

	NFC - 2.6.3
Slide 31	When conducting fire inspections at buildings such as, large storage facilities or large retail stores, ensure you inspect areas of high-piled storage. High-piled storage is defined by NFPA 13 as "solid-piled, palletized, rack storage, bin box, and shelf storage in excess of 3.7m (12 Feet) in height.
	When looking at the storage, determine how the material is stored. Are the heavy items near the bottom, how would water affect the storage, and could the material pose a risk to firefighters?
	To ensure materials are being stored properly you should consult the fire and building code to determine the classification of the product, maximum permitted height of storage according to its base area and shape, and the stability of the stored products.
	The fire code refers to NFPA 13 which gives an extensive description with numerous examples of commodities for classification purposes and should be consulted.
	References:
	NFC
	3.2. Indoor Storage
	A-3.2.1.1.(1) Note
	3.2.3 General storage
	NFPA 13 2019 edition Chapters 3 and 7
Slide 32	The fire code requires adequate access for firefighting purposes be provided and maintained to all portions of the storage area. Access aisles not less than 1.0 m wide must be provided to fire protection equipment and aisles must be maintained free of obstruction.
	In storage rooms the aisle widths may have to be increased. A storage room or area that is greater than 100 m2 must have at least one main aisle with a minimum width of 2.4 m for storage heights of not more than 6m, and 3.6 m for storage heights of more than 6m. The width of main access aisles need not exceed 2.4 m where the products are stored in racks and the building is sprinklered.
	Main access aisles must be accessible from at least 2 directions in the event one becomes unusable.
	References:

	NFC
	3.2.2.2 Aisles
Slide 33	Wall clearances of not less than 600 mm must be provided where stored
	products may swell or expand with the absorption of water.
	In un-sprinklered buildings, a clearance of not less than 1 m between the top of storage and the underside of the floor or roof deck must be maintained to permit hose streams to reach the area.
	In sprinklered buildings, the clearance between the top of storage and ceiling sprinkler deflectors must meet the design specifications of the sprinkler system. All stored combustible materials should be kept away from hot elements of heating equipment.
	Combustible pallets should normally be stored outdoors but some limited quantities are permitted to be stored indoors even in un-sprinklered buildings. Check the fire code for specific details.
	References: NFC
	3.2.2.3 Clearances
	3.2.2.4
	3.2.2.6
Slide 34	 When inspecting rack storage, you should confirm: Storage rack capacity documentation is visible Loads on the storage rack are within rated capacity Loads are stable and secure
	Clearances are within allowable distances
	• That the rack is plumb with no signs of deflection - any deflection of more than ½ ", either vertical or horizontal, should be noted and repaired by a qualified person
	Base plates are secure and anchored to the floor
	Columns and frames show no signs of physical damage
	Horizontal and diagonal struts are in place with no signs of broken welds, missing braces, or braces with rips, tears, or deflection.
Slide 35	Column guards and row end protectors are in good condition
	Check for missing or damaged safety pin connectors
	Pallets are in good condition and not falling apart
	 Pallets are the correct size for the rack and are not overloaded

	 Work areas around the storage racks, such as aisles and hallways, are clear of debris and unobstructed
	The aisle width seems appropriate for the size and type of storage.
	If you have any immediate safety concerns, the rack should be unloaded until it is professionally inspected, and repairs are made as required.
	The following short video talks about 4 American National Standards Institute standards pertaining to identifying, repairing, and replacing damaged racks. One thing to note about the video is that the portable fire extinguisher should be properly mounted and not sitting on the floor.
	There is also a good video by Apex Companies on inspecting rack storage in the additional resources section of this Chapter.
Slide 36	Video.
Slide 37	 Many businesses you inspect will have forklifts for moving material around. The fire code refers to these as Industrial Trucks and provides specific requirements for their operation. Some of the specific requirements are: The use, maintenance, and operation of industrial trucks must conform to NFPA 505 Fuel-fired industrial trucks must conform to ULC/ORD-C558, Battery-powered industrial trucks must conform to ULC/ORD-C583 Fuel-fired industrial trucks shall be stored in detached buildings, or in areas separated from the remainder of the storage area by a fire separation having a fire-resistance rating of not less that 1 h, or in areas where the vehicles will not create a fire hazard to the storage area. Resources:
	NFC 3.1.3 Industrial Trucks
Slide 38	 Fuel-fired industrial trucks must be refuelled at designated locations outside buildings. Fuel-fired industrial trucks that are fuelled by replaceable propane cylinders are permitted to have their cylinders replaced indoors provided cylinder replacement is done at a safe location that is at least 7.5 m from ignition sources, open pits, and underground entrances. The cylinders' valves must be closed, or the engine is operated until the fuel in the system is consumed Spare propane cylinders must be stored outdoors and must be
	supported on raised concrete or other non-combustible platform and be located in a fenced enclosure.

	T
	 Each fuel-fired industrial truck must be equipped with at least one portable extinguisher having a minimum rating of 2-A:30-B:C.
	Resources:
	NFC 3.1.3 Industrial Trucks
Slide 39	Battery-Powered Industrial Trucks:
Silue 39	 Battery-rowered industrial frucks. Battery-charging installations for battery-powered industrial trucks must be located at least 1.5 m from combustible materials, in well ventilated areas, where precautions are taken to prevent ignition sources. Battery-charging stations must be equipped with at least one portable extinguisher having a minimum rating of 2-A:30-B: C. Only trained and authorized personnel are permitted to operate industrial trucks, replace propane cylinders, or refuel fuel-fired industrial trucks, or charge batteries for battery-powered industrial trucks. Like cars and trucks, forklifts are fuel-powered vehicles. But unlike other vehicle types, forklifts frequently operate indoors. So even the smallest
	forklift-related fire can quickly become a big problem.
	Torkint-related fire can quickly become a big problem.
	Resources:
	NFC 3.1.3 Industrial Trucks
Slide 40	Industrial truck fires can be minimized through:
Silue 40	 Regular routine maintenance - that will spot the conditions that could lead to a forklift fire. These include things like leaky propane connectors, buildup of grease or pooling oil on the vehicle, or unsafe electrical connections.
	 Increase Fire Safety Awareness - Forklift operators are the first line of defence against forklift-related fires. Operators should be trained to avoid the conditions that could lead to a fire and what to do in the event one happens. Clean Forklifts Regularly - Cleaning forklift regularly ensures that the
	risk of flammable materials ignition is minimized, even eliminated. • Pay Special Attention to Battery Cables - Batteries are a primary potential ignition source for forklift fires. Protect battery cables from
	damage and inspect them regularly to make sure they aren't damaged. Batteries typically come with an insulated, fire-resistant covering to prevent sparking or arcing. Ensure it is intact and in place during every pre- and post-shift forklift inspection.
	Resources:
	1

	NEC 2.1.2 Industrial Trusks
	NFC 3.1.3 Industrial Trucks
Slide 41	As you conduct your fire inspection, ensure that trash and other waste materials are collected and removed at frequent intervals. Find out where the waste is stored and how often it is picked up. If the building has a waste collection system or room, inspect the area and equipment to ensure that safe housekeeping practices are followed.
	As discussed in Chapter 2, if refuse chutes are incorporated as part of the waste management system, they must be properly fire separated from the remainder of the building or they could create a chimney that can aid in the rapid spread of fire, smoke, and hot gases vertically throughout the building. Chute access doors should be equipped with a fusible link and be self-closing.
	The building code also requires automatic sprinklers to be installed in each linen or refuse chute and in the room or bin into which the chute discharges. Like other fire safety installations regular inspection and maintenance will ensure the system works as designed.
	References: NFC 2.4.1.2 Storage Rooms for Combustible Waste Materials NBC 3.6.3.3 Refuse Chutes
Slide 42	You will come across spray coating operations during you fire inspections. They are usually found in buildings that are occupied by auto shops, cabinet shop and industrial businesses. The fire code says, "The design, operation and maintenance requirements relating to spray coating processes shall conform to NFPA 33, "Spray Application Using Flammable or Combustible Materials." NFPA 33 says that spray applications and processes must be confined to spray booths, spray rooms, spray areas, or in a temporary membrane enclosure meeting NFPA specification.
	The construction and design requirements for spray areas, spray rooms, and spray booths are covered in Chapter 5 of NFPA 33.
	References: NFC 5.4.5.2 NFPA 33
Slide 43	A spray booth is defined as "a power-ventilated enclosure for a spray application, operation, or process that confines and limits the escape of the material being sprayed, including vapours, mist, dusts, and residues that are produced by the spraying operation". There are a few sub-categories of spray

	booths including Dry Particulate, Electrostatic Precipitator, High-Capacity Dry Paint Arrestor, and Water-Wash Spray Booths.
	raint Arrestor, and water-wash spray booths.
	A spray room is defined as "A power-ventilated fully enclosed room with a
	specified fire resistive rating used for flammable or combustible materials.
	References:
	NFPA 33 Chapter 3 Definitions
	NFC 5.4.5.2
Slide 44	Spray operations can only be conducted in Group F Industrial occupancies
	unless the operation is in a room that has a minimum of a 2-hour fire
	separation and is sprinklered in accordance with NFPA 13.
	Spray operations must not be in basements unless there is adequate means of
	egress and access is provided for emergency responders.
	The main hazards associated with spray coating operations are toxicity and
	flammability. Solvents contained in paints often have acute effects on the
	central nervous system, initially causing giddiness and then, with further
	exposure, unconsciousness. These solvents may also be extremely flammable
	especially when atomized in a spray.
	References:
	NFPA 33 Chapter 3 Definitions
	NFC 5.4.5.2
Slide 45	Operation and maintenance procedures for all spray applications should
	comply with the manufacturers specifications and should include but not be
	limited to:
	Spray operations must only be performed in approved facilities
	Combustible residues must not accumulate
	Thin paper or plastic coverings are permitted to facilitate cleaning
	If excessive residue accumulates, spray operations must be discontinued until conditions have been paragraphed.
	discontinued until conditions have been corrected
	 Overspray collectors must be inspected daily, and clogged filters discarded
	All discarded filters must be placed in a non-combustible container with
	a tight-fitting lid or be placed in a water-filled container
Slide 46	Rags or waste materials impregnated with sprayed material must be
	put into an approved waste container immediately after use
	Waste containers must be in a well-ventilated area

- Employees contaminated clothing must be removed from the premises overnight or stored in metal lockers
- Flammable liquids must be kept in covered containers when not actually in use
- Leaked or spilled products must be cleaned up and disposed of promptly and safely

In the automotive industry, many of the paints are now water-based products which provide considerable advantages when it comes to limiting fire and explosion events. In tests conducted most commercially available water-based paints proved to be non-flammable when sprayed, but some paints and other products are still flammable and may present a fire and or explosion hazard.

Slide 47

When conducting your fire inspection, identify any obstructions that block the access or intended use of fire protection equipment. You should ensure storage material is not blocking access to fire extinguishers, pull stations and other fire protection equipment. In this photo the extinguisher is mounted higher than permissible and would be difficult to access.

You should inspect sprinkler rooms to ensure the control valves are accessible and do not have any hanging items on them. In this photo the sprinkler system is obstructed by items stored in the room. A clear unobstructed path to the sprinkler system must be maintained.

You should check that all sprinkler heads have at least eighteen inches of clearance below them, as per NFPA 13. This allows for the proper discharge from the sprinkler head, thus providing an effective spray pattern to control a fire. In this case, pillows are piled on the top rack of a shelving unit obstructing the operation of the sprinkler head. Storage should not be allowed on the top shelf.

Slide 48

The US Fire Administration through the National Fire Academy regularly publish short Coffee Break Training sessions. They have one on the topic of Clearance Beneath Sprinklers. We have added this document to the Additional Resources section of this chapter.

Slide 49

When inspecting kitchen systems for safe housekeeping issues, you should visually check for the accumulation of grease on the hood, exhaust ducting, walls, and cooking appliance surfaces. In this photo grease can be seen around an exhaust fan and running down the wall.

In this photo grease is running down the hood above the appliances.

FireWise Consulting Ltd.

In this case, grease can be seen all over the underside of the hood and dripping off the piping for the fire extinguishing system. You may also note that there is an un-approved light installation which would not conform with the requirements of NFPA 96.

In each case, use of the kitchen should be discontinued until a thorough cleaning is performed by a qualified technician.

If upon inspection, the exhaust system is found to be contaminated with deposits from grease laden vapors, the system must be cleaned by properly trained, qualified, and certified contractors.

Slide 50

You should also visually inspect the filters and ensure they are clean and that the grease tray and grease catchers are not overflowing.

As you inspect the kitchen area, make sure the manual pull station and K class fire extinguisher are clear of any obstructions and workers have a clear egress to the exit.

Emergency lighting is also required in the kitchen.

NFPA 96 is the Standard for Ventilation Control and Fire Protection of Commercial Cooking Operations and is an excellent resource for you when conducting a commercial kitchen inspection. It establishes the frequency for grease inspections based on the type of cooking performed as can be seen in this table.

NFPA 17A is the Standard for Wet Chemical Extinguishing Systems like those found in commercial kitchens. Chapter 7 deals with inspection, maintenance, and recharging.

Slide 51

The benefits of good housekeeping practices are not just about cleanliness; they lay the foundation for accident and fire prevention. It requires attention to details, such as the layout of the worksite or facility, identification and marking of physical hazards, ensuring adequate storage areas are provided, and routine maintenance.

The strategies for good housekeeping should focus on:

- Reducing or eliminating sources of ignition
- Controlling the fuel load
- Providing access to the site for emergency responders
- Providing access to fire protection equipment like sprinkler systems
- Providing and maintaining adequate egress

	Good housekeeping practices result in savings to the building owner so most will buy in once you point this out. There are a few that will not respond positively but usually those are in cases where the business is marginal at best. If you are unable to resolve the deficiencies, you may have to resort to further enforcement action.
Slide 52	Smoking materials are still a major cause of fires even though smoking is not permitted in many occupancies and public places. Regulations that limit smoking have for the most part been effective but have also led to an increase in occurrences where people smoke where they should not or think they are concealed from detection. During inspection you should look for signs of smoking such as discarded cigarette butts and ash cans both inside and outside the building.
	In situations where smoking should definitely be prohibited, no smoking signs in conformance with the fire code, should be prominently displayed. Smoking should always be prohibited around flammable and combustible liquids, flammable gases, dusts, and in areas where they are large quantities of combustibles.
	Where smoking is permitted, an adequate number of ash trays must be provided, and designated smoking area signs should be displayed.
	Reference: NFC 2.4.2 Smoking
Slide 53	Most jurisdictions have some form of recycling facilities be it a landfill or transfer station. The definition of a waste and recycling facility varies, but the goal is to avoid throwing material into a landfill if it can be reused somewhere else. Such materials include plastics, metals, and organics. Traditional hazards in these facilities include aerosol cans, gas tanks, and propane tanks. One growing hazard in recycling facilities is lithium-ion batteries, which have caused smoldering fires and explosions.
Slide 54	The consequences of poor fire safety practices and lack of emergency planning are especially serious in properties where processes or quantities of stored materials would pose a serious threat to the community and environment. In most recycling facilities, the main fire hazards are associated with bulk storage of combustible material and hazardous products. The potential for large fires with negative environmental impacts is significant.
	In an effort to prevent fires, and minimize the damage from fires when they occur, owners and operators of recycling operations and waste handling

facilities are encouraged to develop and implement Fire Safety Plans for their property.

There are lots of papers available on fire safety planning for recycling facilities and waste processing operation. One such guideline, published by the Ontario Fire Marshal's office, is included in the Additional Resource section of this Chapter.

Slide 55

Most waste, including hazardous waste in Canada, is disposed of by compaction and burial or by incineration. The biggest concern with incineration is the residual hazardous waste which must be disposed of in compliance with appropriate regulations.

If incineration is part of the waste processing in your jurisdiction you should be familiar with the type of equipment in use, and the safe operating practices that the facility employs.

The fire code states that the installation and alteration of indoor incinerators shall conform to the Building Code. In the case of outdoor incinerators, the design, construction, installation, alteration and maintenance of outdoor incinerators must conform to NFPA 82 except that the flue venting an incinerator can't serve as the chute conveying waste material to the incinerator.

The fire code also addresses spark arrester's which must be inspected and cleaned at intervals not greater than 12 months or more frequently where accumulations of debris will adversely affect operation. Burned-out spark arresters must be repaired or replaced.

Slide 56

The fire code requires Fire Safety Plans for indoor and outdoor storage in conformance with the fire code. For storage areas the plans must include:

- The product classifications for each different product stored
- The method of storage, including aisle widths for *rack* storage
- The maximum permitted height of storage
- The maximum permitted size of individual storage areas
- Signs must be posted indicating the storage method and maximum height of the goods stored

When the products stored include Group A plastics, rubber products, Level 2 or 3 aerosols, or *dangerous goods*, the fire safety plan must identify the location and maximum quantity of product that is being stored.

22

Reference:

NFC 3.2.2.5 Indoor Storage

June 2021

	3.2.2.5 Fire Safety Plan
Slide 57	In this Chapter we discussed:
	An overview of housekeeping
	The use of a common-sense approach
	Educating the building owners and occupants about good
	housekeeping practices
	 Poor housekeeping can be indicative of other fire safety deficiencies
	 Four major fire and life safety objectives of good housekeeping are to
	Eliminate unnecessary fuel
	Remove obstructions to egress
	Control ignition sources
	Improve safety for firefighters
Slide 58	We also discussed housekeeping on the outside of the building including:
	Obstructed fire dept. access
	Clearly posting the building address
	 Outbuildings, storage sheds, and shipping containers
	Obstructed fire protection equipment
	Utility connections
	Accumulation of garbage
	 Placement of dumpsters and recycling containers
	Flammable and combustible liquid storage
	Wildland fire potential and FireSmart Communities
	We then moved on to housekeeping issues on the interior of buildings
	and talked about dust as a potential fire and explosion hazard and
	section 5.3 of the fire code which is entitled Dust Producing Processes
Slide 59	 Spontaneous ignition of certain materials and that the potential for
	spontaneous ignition can be reduced through good housekeeping
	 Inspecting laundry facilities for lint and the cleaning of dryer vents
	The use of accordion type plastic flexible dryer vents should be strongly
	discouraged – wherever possible smooth sheet metal exhaust ducts
	should be used.
	We talked about the lack of storage space in many buildings
	Stored materials obstructing access to exit
	Materials stored close to ignition sources
	That the fire code does not permit storage in service rooms, crawl
Clid - CC	spaces, or ceiling spaces
Slide 60	Rack storage and discussed clearances, aisle width, and the inspection
	process
	Industrial trucks and forklifts where the use, maintenance, and Industrial must conform to the fire code and NERA FOR
	operation must conform to the fire code and NFPA 505
	Indoor trash and recycling collection and removal

June 2021 23

Fire Inspector Level 1 & II Chapter 13 – Safe Housekeeping Practices

	 Spray coating operations including spray areas, spray booths and spray rooms Obstructions to fire protection equipment Housekeeping in kitchens in conformance with the fire code and NFPA 96 Correction of housekeeping issues We concluded this Chapter with a discussion on controlling smoking and the need for Fire Safety Plans specific to indoor and outdoor storage.
Slide 61	Chapter quiz.
Slide 62	That's the end of Chapter 13 - Safe Housekeeping You are now ready to move on to Chapter 14 which deals with Writing Reports and Keeping Records but please complete the Quiz for chapter 13 first. If you have any questions now is a good time to contact your instructor.

June 2021 24